

# GIpro X-type G2

## Install Guide for **GPX-HY1** Harness Kit

Before installing this Harness Kit, please make sure you got the right parts for your bike. See the part numbers on the packaging and use the **Product Advisor** on our website to check compatibility.

These instructions are applicable to a wide range of motorcycles and describe the main install steps needed for a successful installation.

You can find motorcycle specific Supplementary Manuals on our website. Please visit:

[www.healtech-electronics.com/GPXT](http://www.healtech-electronics.com/GPXT)

***Disclaimer:** Do not attempt to install the product if you don't have basic mechanical skills. HealTech Electronics Ltd. and its distributors shall not be liable for any loss or damage caused by improper installation. If in doubt, please consult with your dealer.*

- 1.** Locate the **Speed Sensor coupler**. It is behind the instrument cluster: 3-pole connector with Black/White, Green and Orange wires.  
If in doubt, trace the cable from the front wheel sensor until you find the coupler.

Confirmation:

Separate the Speed Sensor coupler (you might need to use a small flathead screwdriver to get the coupler apart). Rotate the front wheel while the ignition is on. Does the speedometer show 0, turn the ignition off and proceed to the next step. Otherwise, try again since you have disconnected something else.

- 2.** After separating the Speed Sensor coupler, **plug in** both the male and female 3-pole GIpro harness connectors. Make sure the connectors are fully seated.
- 3.** Find the **Pick-up coil signal wire**.  
The Pick-up coil is at the Magneto/Generator. Find the **Green** signal wire either at the 2-pole connector of the pick-up, or at the ECU connector.

4. Connect the GIpro **Black/Green** wire to the **Pick-up coil signal wire**, using the **Red wire tap** connector supplied.

*Usage: Place the unstripped signal wire inside the run channel. Close the side cover until latched. Cut off the excess length, then insert the unstripped tap wire (Black/Green) completely and check its position. Insert the blade (u-contact) and press down by finger pressure. Then, fully depress the u-contact with pliers. Close the hinged top cover until latched.*

5. Connect the 4-pole GIpro harness connector to the GIpro display connector.

6. Check whether everything is installed and working properly:

- **Select Neutral and turn ignition On** →

The GIpro display should count from **6** to **1**, then "**L**" flashes slowly.

*(If not, the display is not receiving power and/or ground. Check the connections at the speed sensor connector.)*

- **Rotate the wheels** → the display should indicate a rolling wheel.

*(If not, the display is not receiving the speed signal. Check the connection at the speed sensor connector.)*

- **Start the engine** → "**L**" should flash **faster** for a few seconds.

*(If not, the display is not receiving the RPM signal. Check the wire tap.)*

Turn the ignition Off. If the tests still fail, disconnect the 3-pole and 4-pole connectors and check whether the connector pins are bent or pushed out of position. Spray some WD40 into the plugs.

7. Peel off the green plastic from the back of the unit, and mount the display.

8. Neatly route the GIpro harness from the 3-pole plugs to the mounting location, preferably along the frame.

Do not bend the harness near the 4-pole connectors.

Do not route the harness very close to the exhaust pipe or cylinder head.

9. Use black tape to secure and isolate the 4-pole connectors. To minimize cable stress, use the supplied cable ties to fasten the unit and harness to other cables.